



INSTRUCTIONS

Bulb Fitment

Please note for transportation purposes the bulb supplied with this product has not been fitted. Remove it from its packaging and install as indicated below prior to first using your Autofade Bedside Lamp.

Autofade Bedside Light Operation

The Babytec Autofade Bedside Light combines the advantage of a touch sensitive dimmer and a delayed switch-off light. The top sensor switches the light on or off with a momentary touch. If contact is held on this sensor the light will dim or fade until the contact is released. The light level will remain at this setting until the light is either switched off, the level is adjusted or the autofade is activated.

The bottom sensor activates the automatic fade and switched off. When this sensor is touched, even only momentarily, the light level will slowly fade and switch off, from whatever light level it was set at. The time taken for the light to switch off depends upon the level set when the autofade was activated. From full brightness, this takes approximately 15 minutes. The autofade can be overridden by touching the main sensor and resetting the light level. When the light is near to switching off, it is possible to detect the changing light levels. This is normal and is not a defect in the product.

Replacing the Bulb

1. The light must be disconnected from the mains supply before removing the cover. Remove the plug from the socket.
2. Holding the light upside down, remove the screw that is visible in the base moulding.
3. Turn the light the right way up and put the base on a flat surface.
4. Holding the base moulding in both hands, press the centre front of the diffuser inwards and upwards to remove.
5. Remove the bulb by rotating it anticlockwise.
6. The new bulb must be of the small screw cap type, with a maximum power of 25 Watts. Insert the bulb in the bulb holder and rotate clockwise.
7. Replace the diffuser by placing it on the base moulding and pressing inwards and downwards at the centre front.
8. Turn the light upside down and replace the screw in the base.

A replacement bulb is easy to obtain. The bulb supplied with the lamp is a small screw cap SES 25W. A bulb exceeding 25 Watts creates excess heat in the lamp. Maximum height of bulb should be 85mm from base or bayonet.

Please note: The light is a sealed unit and should only be repaired by the manufacturer.

Important: Never allow the lamp to be covered whilst in operation and always use in an upright position on a flat surface.

Service

Your Babytec product is guaranteed for 2 years from date of purchase. Should you have any problems, first check the bulb is functioning, the fuse in the mains plug and that the mains supply is switched on.

If problems persist you can call the **Babytec Helpline** on **01935 812732** or return the complete unit to our service department.

Babytec Address: **Babytec International Products Ltd**
First Floor 3 Priestlands Lane
Sherborne Dorset DT9 4HL UK
Tel: 01935 812732 Fax: 0560 2043694
www.babytec.co.uk



Model Number: 5000 / 5001 / 5050 / 5051